


## AKKOtune compact V4

### New Control Panel



## Troubleshooting Checklist

In order to find out the error source the troubleshooting checklist is to be gone through step by step.

- |   |     |    |
|---|-----|----|
| 1. When connecting the external power supply does the blue LED (1) light up?          | Yes | No |
| 2. When turning the speed knob (2) right do the LEDs (3 and 4) light up?              | Yes | No |
| 3. When turning the speed knob (2) right does the back light of the display light up? | Yes | No |

If all questions above are answered YES, check whether the little button (6) is free and not stuck. To do this, press the button lightly – you should feel and hear a clicking; if not, the button is stuck and needs to be released, which is easy. If NO check the fuse (11) on the side of the front panel.

- |  |     |    |
|--|-----|----|
| 4. Adjust the speed knob between 3 and 5, and press the PUSH button.<br>Do you hear a sound from the blower?                 | Yes | No |
| 5. If the Reverse-Switch (7) is in the position normal does the air blow<br>out of the blow hole on top of the tuning table? | Yes | No |
| 6. Does the display (5) show any change of the reading?  | Yes | No |
| 7. If you now press the “momentary stop”-button (6) does the wind stop?  | Yes | No |
| 8. If you release the “momentary stop”-button does the wind come back?   | Yes | No |
| 9. Try the same with the PULL button, does it work?  | Yes | No |
| 10. Use the Reverse-Switch (7); do the PUSH and PULL buttons as expected?  | Yes | No |

If you have all question above answered YES you have no troubles.

If you have a NO please tell me at which position.

[questions@akkofixx.com](mailto:questions@akkofixx.com)